

Train the trainer

PUSH-BUTTON WATERBRUSHES

3 SECOND SELL

- 1 Push-button for easy control water release
(Leak-proof design)
- 2 Durable nylon fibre tip holds shape and point
- 3 Point and chisel tip options for a range of strokes



DERWENT

Train the trainer

1



PUSH-BUTTON FOR EASY CONTROL WATER RELEASE

Rather than squeezing a full barrel to release water, this range features a push-button, meaning artists have greater control over how much water is released at any time.

The barrel can be easily cleaned and refilled by unscrewing near the tip.

DURABLE NYLON FIBRE TIP HOLDS SHAPE AND POINT

The preferred choice by artists for refillable waterbrushes, this range features robust nylon fibre tips which hold their shape and point over time; important for ensuring fine detail and effects can be achieved.

2



3



POINT AND CHISEL TIPS FOR A RANGE OF STROKES

The Derwent Push-Button Waterbrush range features a range of tip options; available as an assorted 4 pack, or individually.



2mm
FINE TIP



3mm
MEDIUM TIP



4mm
LARGE TIP



10mm
LARGE
CHISEL TIP