

## **Equipment Cabinet Assembly**

It is a good idea to assemble the Equipment Cabinet on carpet to avoid scratching. If this is not possible, you can use the box the parts came in as a work surface. (Be sure to remove all staples!)


Insert 2 Cam Locks (J) into each Side Panel (B & C). Next, insert 4 Steel Pins (M) into the predrilledholes, tightening until snug. Finally, attach 2 Hinge Mounting Plates (K) to the predrilled holes on each Side Panel. (The arrow on the Mounting Plate should point towards the edge of the panel).






Assemble Side, Back, and Shelf panels as shown. First, lay the Left Hand Side (B) on the floor. Slide the Back (D) and shelf (E) Panels onto the Steel Pins of the Left Side. (Be sure the edges of the Back and Side Panels are flush).

Using a Screwdriver, turn Cam Locks (J) clockwise 180° degrees to lock in place. Slide Right Hand Side onto the Back and Shelf; tighten remaining Cam Locks.






Hardware & Parts List					
		M	Market N		
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
A B C D E F G H I J	TOP ASSEMBLY LH SIDE PANEL RH SIDE PANEL BACK PANEL SHELF RH DOOR ASSEMBLY LH DOOR ASSEMBLY METAL BASE COMBO SCREW CAM LOCK	1 1 1 1 1 1 1 4 12	L	HINGE MOUNTING PLATE HINGE (pre-attached to door) STEEL PIN LOCK (pre-attached to door) LOCKING CASTER CASTER KEYS BUMPER (BLACK) SCREWDRIVER - (1) PHILLIPS	4 4 12 1 2 2 2 2


Turn Cabinet upside down (Shelf should be closer to the floor). Place Metal Base (H) onto Sides and Back of the Cabinet. (Back of the Base has lip extending outwards). Line up 2 holes in each side with holes in Metal Base (H). Insert a Combo Screw (I) ineach of the 4 holes and tighten.

Insert the two Locking Casters (O). (Locking Casters should be in the front of the unit). Insert the other two Casters (P) and turn the Cabinet to upright position.



Place complete Top Assembly (A) onto the Cabinet with Tray opening to the desired side. Line up Steel Pins (M) with the holes on the top edges of the Sides. Tighten all 4 Cam Locks (J) on the Sides.

NOTE: The unit can be assembled so the Tray can be pulled out to the right or the left.




Next, attach Doors (F & G) to the Cabinet.
First, position Door (see inset) so screw in
Hinge Mounting Plate (K) can be placed
through "keyhole" in Hinge (L). Secure Hinge
using Slotted Screwdriver. Install one Door
before proceeding with the next.

NOTE: These Door Hinges havea "snap" action to keep Doors closed.

Close Doors completely and check for alignment. Adjust if necessary. Apply (1) Black Bumper (R) to the lower inside corner of each door as shown).

Cabinet Assembly is now complete!





## ASSEMBLY INSTRUCTIONS FOR EQUIPMENT CABINET GBC PART NUMBER 1154314



Thank you for purchasing this equipment cabinet. The cabinet can be easily assembled by following these instructions.

Unpack the carton making certain to remove each part. Check all parts against the parts list on the next page. Call General Binding Corporation for replacement of any missing parts.

CAUTION Do not place equipment on this cart should the cart appear unstable. An unstable cart may cause the equipment to fall resulting in serious bodily injury. Avoid quick stops, excessive force, power cords and uneven floor surfaces when moving the cart.

Please call General Binding Corporation with any questions regarding assembly of the cabinet.



One GBC Plaza Northbrook, IL 60062 800/723-1500 49 Railside Road Don Mills, Ontario M3A 1B3